



IS-6291

#### INSTALLATION INSTRUCTIONS

1. DISCONNECT POWER FROM THE FUSE BOX.
2. EXPOSE WIRING FROM OUTLET BOX.
3. FASTEN THE MOUNTING CROSS-BAR TO THE OUTLET BOX USING THE TWO SCREWS SUPPLIED WITH THE OUTLET BOX.
4. ATTACH COPPER GROUNDING WIRE FROM FIXTURE TO GREEN GROUNDING SCREW ON MOUNTING CROSS-BAR.
5. MAKE WIRE CONNECTIONS IN OUTLET BOX.
6. SCREW NIPPLE INTO CROSS-BAR, SLIDE CANOPY OVER OUTLET BOX. TIGHTEN CANOPY ON WITH SCREW-COLLAR.
7. ATTACH CHAIN TO SCREW-COLLAR AND LOOP ON FIXTURE.