

## Installation Information

Item #P0126

Leg Tub Diverter Gooseneck Faucet, 3 3/8" Centers

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

1. Shut off the water supply before installation.
2. Insert the faucet inlets through the 2 holes on the tub, at 3 3/8" centers. Screw the lock nuts onto the threaded shanks and tighten faucet to tub.
3. Attach the spout and tighten the hold down nut to hold in place.
4. Attach handles using the handle screws provided.
5. Make no adjustments to valves or valve stems. They are tested at the factory for optimum performance.

