

Installation Information

Item #P0698 – 57" x 31" Enclosure with Support Braces AND P0709 Riser

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

Note: If not using with a riser, then proceed to step 3.

1. First slip the wall tee onto the shower riser about 10" below the crook in the riser. Only tighten slightly as later an adjustment will most likely be necessary. Connect portions of the riser with the union nut.
2. Install the riser onto the faucet, making sure that the riser is fully inserted into the female portion of the faucet.
3. **Please note: Many leg tubs are slightly slanted on the end. The enclosed riser nut and large cone washer have been designed to compensate for this fact. It is important to only hand tighten the riser to the faucet, then make the riser vertical using the wall and ceiling braces, and finally tighten the riser nut.**
4. **Two people are needed for the remaining steps.** Use the wall tee to connect the two smaller sections together by inserting each side into the sides of the tee. Be certain that the threaded hole on the tee ends up facing toward the outside of the ring to the wall. You will insert the wall support here. Insert the tee screws and tighten.
5. Take the ceiling tees and slip them into the free ends of the smaller sections. Be certain that the threaded hole of the tee is facing toward the ceiling. You will insert the ceiling supports here. Insert the tee screws and tighten.
6. Slide the larger "C" shaped section of the enclosure into the other side of the tees and insert the tee screws and tighten.
7. After measuring the proper length that the wall and ceiling braces need to be, cut these pieces off the unthreaded end to the desired length. **DO NOT TAKE THE THREADED PORTIONS OF THE BRACES INTO ACCOUNT WHEN MEASURING THE BRACES.**
8. Install the escutcheons onto the wall and ceiling in their proper positions.
9. Very carefully screw ceiling braces firmly into the ceiling tee. Take care not to flex this joint a great deal. As you then install the ceiling braces into the ceiling escutcheon and tighten the screw, someone must hold steadily the other end of the shower ring to reduce flex.
10. Very carefully screw the wall brace firmly into the wall tee and do not allow the joint to flex. You may now adjust part A to the desired height on the riser. Install the wall brace into the wall escutcheon and tighten the screw.

