





FRONT VIEW

**BACK VIEW** 

Packed with 2 cutting neck 2" machine screws.

For doors 1-3/8" ~ 1-3/4" thick.

View hole location may vary.

It is not recommended to use this schematic for door preps.

DRAWING NOT TO SCALE

NOTE: Deltana reserves the right to constantly improve its products and is not responsible for differences between the product in-hand and the specifications contained in this drawing. We do not recommend to pre-drill holes or pre-cut woods or metals based on the drawing information if the veracity of the specifications has not been proven by the live product.