

Assembly instructions for the 4415 BB / PW /  
OB

---

fixture construction:

1. First find a clear area in which to work.
2. Unpack all components from the carton and lay them out.
3. Slip Center Column assembly (2) along wire and thread into coupler (A) located in the top center of main body assembly (1), and tighten.
4. Thread bottom finial assembly (3) into bottom of main body assembly (1) and tighten.
5. Slip candle sleeve (4) over socket (B).
6. Slip candle chaser (5) over candle sleeve (4).
7. Fixture is complete and ready for installation.



