



FIGURE 1

INSTALLATION INSTRUCTIONS:

1. Before beginning installation, carefully unpack all parts referring to illustration FIGURE 1.
2. Turn power to installation point OFF. Locate the UNIVERSAL CROSSBAR and attach to the OUTLET BOX with (2) OUTLET BOX SCREWS(not supplied).
3. Make the connections: **(Quoizel recommended 2 people for this step)** locate and attach the HOUSE GROUND WIRE and FIXTURE GROUND WIRE. Proceed to attach both to the UNIVERSAL CROSSBAR with the GREEN GROUND SCREW. Use wire connectors (not supplied) attach the HOUSE WHITE WIRE to the FIXTURE WHITE (or RIBBED) SUPPLY WIRE; connect the HOUSE BLACK (or RED) WIRE to the FIXTURE BLACK (or SMOOTH SIDE) WIRE. Wrap at connections with approved electrical tape.
4. Carefully tuck all wires into the OUTLET BOX and position the fixture over the OUTLET BOX. Align the (2) MOUNTING HOLES in the BACKPLATE with the (2) MOUNTING SCREWS attached to the UNIVERSAL CROSSBAR. Pass the fixture over the screws and secure against by threading (2) MOUNTING BALLS onto the ends of screw. Tighten until snug.
5. Locate the SHADE HOLDER over SOCKET onto COVER. Proceed to locate SHADE over SOCKET seating into SHADE HOLDER. Using SOCKET COLLAR TOOL, thread the SOCKET COLLAR onto SOCKET and tighten until snug to secure the SHADE.
6. Install the BULB and check the lamp markings or labels for maximum wattage.
7. Restore power to the installation point ON. Retain this sheet for future reference.



***IF IN DOUBT ABOUT ELECTRICAL INSTALLATION,
 CONSULT A LICENSED ELECTRICIAN!***