

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Assembly & Installation Instructions

1. Shut off power to outlet box (Fig A).
2. Make appropriate electrical connections using wire nuts:
 - a. Connect the fixture's hot wire (black) to the black outlet box wire.
 - b. Connect the fixture's neutral wire (white) to the white outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
3. Place mounting plate over outlet box and secure it with outlet box screws. Using the mounting screws and anchors for extra support.
4. Attach back plate over mounting plate (Fig B) and tighten with back plate screws on top.
5. 1835 - Insert T10 medium base bulb in socket (not included).
1835F - Insert 18W quad CFL G24q-2 base bulb (not included).
6. Attach shade to shade holder using spring clips.
7. Restore power to fixture.

CARE INSTRUCTIONS

Dusting – Use a clean, dry cloth.
Cleaning – To protect the finish, avoid any harsh abrasives or chemicals.

