

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CH38303

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps

1. Attach the nipple-1 to the mounting strap, and then secure with a washer and a hex nut.
2. Attach the mounting strap to the ceiling box by using two mounting screws.
3. Secure the rod onto the nipple-2 tightly.
4. Unscrew the set screws from the fixture, attach the silhouettes onto the fixture, and secure with the set screws.
5. Choose the certain length of the chain that you need, and then weave the fixture wire and the grounding wire through the chain. Then connect one end link of the chain and the loop by using the loop lock.
6. Secure the top loop to the nipple-1 tightly.
7. Thread the fixture wire and grounding wire through the collar, canopy, top loop, nipple-1 and mounting strap in order.
8. Connect the other end link of the chain and the top loop by using the loop lock.
9. Make wire connections with wire nuts:
 - The smooth wire (marked) from fixture to the black wire from power source.
 - The ridged wire (unmarked) from fixture to the white wire from power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with the wire nut.Carefully tuck wires back into the ceiling box.
10. Attach the canopy to the mounting strap by inserting the top loop, and then secure with the collar.
11. Attach the glass shades upwards to the glass holders, and then secure with the socket rings.
12. Install bulbs. **(Please do not exceed the maximum capacity that is recommended on the package.)**
13. Turn on the power at fuse or circuit box.

