

ASSEMBLY AND INSTALLATION INSTRUCTIONS

FL33075

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps

1. Attach the lower pipe onto the connector on the base by rotating the lower pipe.
2. Secure the connector into the lower pipe, and then attach the middle pipe onto the connector by rotating the middle pipe.
4. Secure the connector into the middle pipe, and then attach the upper pipe onto the connector by rotating the upper pipe.
5. Attach the antler onto the upper pipe, and then rotate it tightly.
6. Squeeze the arms of the harp together and fit them into the retainer, then lower the sleeves to fix them.
7. Attach the shade to the harp, and secure with the finial.
8. Install bulb. **(Please do not exceed the maximum capacity that is recommended on the package.)**
9. Insert the plug into the wall receptacle.
10. Control the lamp with the switch.

NOTICE: Purchase the 3-way bulb to have 3-way switch control:

off → 50Watts → 100Watts → 150Watts.

