

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OD33486 / OD33586 / OD35086 / OD36986 / OD35686

WARNING: TO AVOID RISK OF ELECTRIC SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps:

1. Attach the nipple-1 to the mounting strap, and secure with the washer and lock nut.
2. Attach the mounting strap to the ceiling box by using 2 mounting screws.
3. Secure the loop to the nipple-2.
4. Take a certain length of the chain you need, and weave the fixture wire and the grounding wire through the chain links. Spread one end of chain link to clamp securely to the loop.
5. Secure the top loop to the nipple-1.
6. Thread the fixture wire and grounding wire through the collar, canopy, top loop, nipple-1 and mounting strap in order.
7. Clamp the other end of chain link to the top loop.
8. Make wire connections with wire nuts:
 - Connect smooth wire (marked) from fixture to black wire from power source.
 - Connect ridged wire (unmarked) from fixture to white wire from power source.
 - Attach the grounding wire and house grounding wire to the mounting strap with a green grounding screw.Carefully tuck wires back into the ceiling box.
9. Attach the canopy to the mounting strap by inserting the top loop, and secure with the collar.
10. Install a bulb. (Please do not exceed the maximum capacity, which is recommended on the package.)
11. Turn on the power at fuse or circuit box.

