

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

PD33082

**WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.**

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THIS INSTRUCTION.**

1. Attach the nipple to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Choose two certain same length of the chains you need, and then weave the fixture wire and fixture grounding wire through the chain links. Then connect the chains to the fixture loops by using the loop locks.
4. Thread the fixture wire and fixture grounding wire through the canopy loops and canopy in order.
5. Connect the other end of the chains to the canopy loops by using the loop lock.
6. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
  - The smooth wire (marked) from the fixture to the black wire from the power source.
  - The ridged wire (unmarked) from the fixture to the white wire from the power source.
  - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.Carefully put the wires back into the outlet box.
7. Attach the canopy to the mounting strap by inserting the nipple, then secure it with the finial.
8. Attach the glass shades to the glass holders, then secure them with the socket rings.
9. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
10. Turn on the power at the main fuse or circuit breaker box.

