

ASSEMBLY AND INSTALLATION INSTRUCTIONS

PD65221

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THIS INSTRUCTION.**

1. Attach the short nipple to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Secure the top loop to the short nipple.
4. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain, collar and canopy.
5. Connect one end of the chain with the loop by using a quick link.
6. Connect the other end of the chain with the top loop by using a loop lock.
7. Thread the fixture wire and fixture grounding wire through the top loop, short nipple and mounting strap.
8. Pull out the outlet wires and house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - The smooth wire (marked) from the fixture to the black wire from the power source.
 - The ridged wire (unmarked) from the fixture to the white wire from the power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.
9. Carefully put the wires back into the outlet box.
10. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.
11. Screw the long screw into the coupling under the socket, then secure it with a washer and hex nut.
12. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
13. Slip the glass shade and the cap with the open side facing downward through the long nipple until it checks the bottom of the fixture, and secure it with a hex nut.
14. Slide the decorative up to the glass shade, secure it with a hex nut.
15. Slide the cover up to the decorative and secure it with the finial.
16. Secure the pine cones and pine needles onto the set screws of fixture as shown in right graph.
17. Turn on the power at the main fuse or circuit breaker box.

