

ASSEMBLY INSTRUCTIONS FOR 9405

IMPORTANT

**TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX
BEFORE STARTING INSTALLATION**

