




Family: Mondrian | Item No. 4577 KZ




Drawing 1 - Strap Detail



Drawing 2 - Fixture Mounting



Drawing 3 - Fixture Assembly



▼ start here

1

1. Find a clear area in which you can work.
2. Unpack fixture and glass from carton.
3. Carefully review instructions prior to assembly.

***** The construction of this fixture will be accomplished by first determining the length of stem required, mounting the mounting strap to the junction box, making all necessary electrical connections, hanging the fixture from the ceiling, and then installing the glass.**

2

1. Determine the overall length you will need the assembled fixture to be.
2. Determine what stem will be needed to achieve the overall length you require. (Additional stems are available and can be ordered. Ask your local Hinkley Lighting representative or visit www.hinkleylighting.com for information.)
3. Install stems by slipping them onto the supply wire of the fixture, threaded end up, and threading them together - see **Drawing 3**.

3

1. Prepare gem strap (**A**) for mounting by threading two screws (**B**) provided into back of gull wing bracket of gem strap (**A**) - see **Drawing 1**.
 - Be sure the holes into which the screws are threaded match the spacing of holes (**D**) in the canopy (**E**) - see **Drawings 1 and 2**.
3. Mount gem strap (**A**) to junction box (**J**), using the two 1" screws (**C**) provided.

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

4

Make electrical connections from supply wire to fixture lead wires. Refer to instruction sheet (**I.S. 18**) and follow all instructions to make all necessary wiring connections.

5

1. Hang the fixture by slipping the holes (**D**) in the canopy, over the screws (**B**) in the mounting strap - see **Drawing 2**.
2. Thread on ball knobs (**F**) to secure fixture to the ceiling.

Note: Maximum wattage for 4577 fixture is 100 watts per bulb.

10.29.09