

Installation Information

Tub Only Set

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

1. The maximum wall thickness is 1 1/2".
2. Rough in the valves from the back of a finished wall, assuring there is a proper distance for escutcheons and handles on the valve stems.
3. The spread between the Hot and Cold valves is **8" on center** with supplied nipples connected to the supplied Tee.
4. Connect the Hot & Cold valves to 1/2" iron pipe size water supply, where the union and large nut are pointed down.

