

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OF50511

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THIS INSTRUCTION.**

1. Attach the nipple to the mounting strap, then secure it with a washer and hex nut.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Unscrew the bolt nuts and remove the frame away from the ceiling pan.
4. Gently place a bigger flat glass into the bottom of the interior frame, secure it by placing 8 pieces of "S" clips (two on each side of the interior frame) into position. (See Fig.1 & Fig.2)
5. Gently place four smaller flat glasses into four sides of the interior frame into position as shown in Fig.5. With one side locating into the slot of "S" clip, secure the flat glasses by pressing the clips. (See Fig.3 & Fig.4)
6. Pull out the outlet wires and house grounding wire from the outlet box. Make wire connections using the wire nuts:

- The black wire from the fixture to the black wire from the power source.
- The white wire from the fixture to the white wire from the power source.
- Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully put the wires back into the outlet box.

7. Attach the ceiling pan to the mounting strap by inserting the nipple, then secure it with the end cap.

CAUTION: With silicone caulking compound, caulk completely around where back of ceiling pan meets with the ceiling surface to prevent water from seeping into the outlet box.

8. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
9. Restore the frame back to the ceiling pan using two bolt nuts.
10. Turn on the power at the main fuse or circuit breaker box.

